

# **EC6 Module**

## **User Manual**

**Applicable model:**  
**EC6**

**JIANGSU SFERE ELECTRIC CO., LTD.**

## **Safety instructions**

Thank you for choosing the products developed by Jiangsu Sfere Electric Co., Ltd. In order to facilitate your purchase and help you use this product safely, correctly and efficiently, please read this manual carefully and pay attention to the following points when using it.

### **CAUTION:**

- ◆ Make sure only the qualified technicians perform the installation and maintenance;
- ◆ Before performing wiring operation to the meter, make sure the input signal and the power supply are switched off;
- ◆ The proper voltage detecting device should be used to guarantee no voltage in any part of the meter;
- ◆ The electrical parameters supplied should be within the rated range;

### **The following situations may result in damage to the device or cause mistakes in the operation of the device:**

- ◆ The voltage of the auxiliary power supply goes beyond the rated range.
- ◆ The frequency of the power distribution system goes beyond the rated range.
- ◆ The input polarity of the voltage or the current is incorrect.
- ◆ Remove or connect the communication plugs without powering off.
- ◆ Connect the terminal wires against the related instructions.



**Please don't touch the terminals  
when the meter is in operation!**

The latest manual can be downloaded from the company's homepage and some corresponding test software downloads also provided. If you need an electronic user manual, you can obtain it from our technical service department.

# Catalog

1 Product Introduction.....	1
1.1 Summary.....	1
2 Technical specifications.....	1
2.1 Technical parameter.....	1
2.2 Main function.....	2
3 Dimensions and wiring diagrams.....	3
3.1 Size.....	3
3.2 Wiring.....	3
4 Operation.....	4
4.1 Panel.....	4
4.2 Use Preparation and Function Description.....	4
4.2.1 Hardware preparation.....	4
4.2.2 Light Function Description.....	4
4.2.3 Key function description.....	4
4.3 Parameter configuration and reading.....	5
4.3.1 Parameter reading.....	6
4.3.2 Parameter configuration.....	7
4.4 Firmware upgrade.....	8
4.4.1 Access IAP.....	8
4.4.2 Firmware update.....	9

# 1 Product Introduction

## 1.1 Summary

EC6 module is a wireless transmission module based on NB-IoT mode, using the existing mobile network can easily let your device achieve wireless connection with Internet. It has many advantages, such as wide network coverage, flexible and fast networking.



Figure 1.1 product physical figure

## 2 Technical specifications

### 2.1 Technical parameter

Project		Parameters
Wireless Interface	Frequency band	B3/B5/B8
	Network type	NB-IoT
	SIM card voltage	3V、 1.8V
	Antenna interface	50Ω/SMA(female head)
RS485 Interface	Communication	half duplex
	Communication baud rate	2400～19200bps,default 9600bps
	Data format	n81/n82/o81/e81,default n81
Main	Model	PD194Z-E1X


module	
Working environment	-25°C~70°C, ≤93%RH
Storage environment	-40°C~85°C, ≤93%RH

## 2.2 Main function


- ✧ Support dynamic domain name or IP address access.
- ✧ Support break line automatic reconnection function.
- ✧ Support local graphical interface configuration and maintenance.
- ✧ Have Reset key, can restore to factory configuration in case of system parameter configuration confusion.
- ✧ Support local firmware update capability to facilitate user to update the device.

### 3 Dimensions and wiring diagrams

#### 3.1 Size




#### 3.2 Wiring



## 4 Operation

### 4.1 Panel



### 4.2 Use Preparation and Function Description

#### 4.2.1 Hardware preparation

The EC6 module is spliced with PD194Z-E1X series of instruments, the RS-485 interface of the EC6 module is connected to the computer, the SIM card is inserted, the antenna is connected to the antenna interface, and then the power is on.

#### 4.2.2 Light Function Description

There are two small lights on the panel: Run and Com.. The function of each lamp is described in detail below.

1. All small lights flash once after power on, then the Run light is always on.
2. Connect server successfully, Com light flash slowly.
3. Data interaction with the server, Com lights flash quickly.

#### 4.2.3 Key function description

Reset key have the following functions:


1. The Run indicator is always on. Press the Reset button to enter the configuration mode. The Run indicator flashes.
2. The Run indicator flashes, press the Reset button to launch the configuration mode, the Run indicator is always on.
3. Press and hold the Reset button for 3-4 seconds to release, all indicator lights flash quickly, and the EC6 module is reset.

4. Press and hold the Reset button for more than 10 seconds to release, all the indicators flash slowly, the EC6 module restores the factory settings

### 4.3 Parameter configuration and reading


Connect the RS-485 interface of the EC6 module with the PC, open the SmartConfigTool software and set the serial port parameters (baud rate :9600, data format: N81), press the Reset button to enter the configuration mode.

Click on the import configuration option under the SmartConfigTool file menu, select TGate.xlsx profile to import the configuration parameters.




#### 4.3.1 Parameter reading

Click the Parameter Read button to read the configuration parameters within the module.



### 4.3.2 Parameter configuration


Change the value of the parameter in a column of values as required. After the parameter is set, click the parameter configuration button to write the parameter inside the EC6 module and save it



## 4.4 Firmware upgrade

### 4.4.1 Access IAP

Click the firmware upgrade option under the SmartConfigTool software tools menu in configuration mode, pop up IAP Tool the upper computer, set the serial port parameters (baud rate :9600, data format: N81). Select Protocol Sfere, Click Enter IAP. Enter successfully, Run light flashes quickly.



#### 4.4.2 Firmware update

Open the firmware file and click send, waiting for the firmware update to complete. pop up the send finish prompt box. If checked complete enter APP, close prompt box and enter application execution. .

